




INTERNATIONAL APPLICATION PUBLISHED UNDER THE PATENT COOPERATION TREATY (PCT)

(51) International Patent Classification 7 : C08G 18/00	A2	(11) International Publication Number: WO 00/64957 (43) International Publication Date: 2 November 2000 (02.11.00)
--	----	---

(21) International Application Number: PCT/US00/11072 (22) International Filing Date: 26 April 2000 (26.04.00) (30) Priority Data: 60/130,988 26 April 1999 (26.04.99) US (71) Applicant (for all designated States except US): U.S. ARMY MEDICAL RESEARCH AND MATERIAL COMMAND [US/US]; Department of Army, Command Judge Advocate Office, 504 Scott Street, Fort Detrick, MD 21702-5012 (US). (71)(72) Applicants and Inventors: GORDON, Richard, K. [-US]; 9024 Willow Valley Drive, Potomac, MD 20854 (US). DOCTOR, Bhupendra, P. [-US]; 10613 Great Arbor Drive, Potomac, MD 20854 (US). (74) Agents: WISEMAN, Thomas, G. et al.; Morrison & Foerster LLP, 2000 Pennsylvania Avenue, N.W., Washington, DC 20006-1888 (US).	(81) Designated States: AE, AG, AL, AM, AT, AU, AZ, BA, BB, BG, BR, BY, CA, CH, CN, CR, CU, CZ, DE, DK, DM, DZ, EE, ES, FI, GB, GD, GE, GH, GM, HR, HU, ID, IL, IN, IS, JP, KE, KG, KP, KR, KZ, LC, LK, LR, LS, LT, LU, LV, MA, MD, MG, MK, MN, MW, MX, NO, NZ, PL, PT, RO, RU, SD, SE, SG, SI, SK, SL, TJ, TM, TR, TT, TZ, UA, UG, US, UZ, VN, YU, ZA, ZW, ARIPO patent (GH, GM, KE, LS, MW, SD, SL, SZ, TZ, UG, ZW), Eurasian patent (AM, AZ, BY, KG, KZ, MD, RU, TJ, TM), European patent (AT, BE, CH, CY, DE, DK, ES, FI, FR, GB, GR, IE, IT, LU, MC, NL, PT, SE), OAPI patent (BF, BJ, CF, CG, CI, CM, GA, GN, GW, ML, MR, NE, SN, TD, TG). Published <i>Without international search report and to be republished upon receipt of that report.</i>
---	--

(54) Title: DIFFERENTIALLY ACTING OP DETOXIFYING SPONGES



Final product: FBS-AChE sponge

(57) Abstract

A material comprising a porous support and a plurality of enzymes for the removal, decontamination or neutralization of hazardous chemicals such as OP compounds is disclosed. The material may be used on a variety of surfaces, including natural, synthetic and biological surfaces such as skin and other delicate membranes. Also disclosed is a process of making the material, kits and various methods and reactivation devices for reactivating the enzymatic activity of the material.

FOR THE PURPOSES OF INFORMATION ONLY

Codes used to identify States party to the PCT on the front pages of pamphlets publishing international applications under the PCT.

AL	Albania	ES	Spain	LS	Lesotho	SI	Slovenia
AM	Armenia	FI	Finland	LT	Lithuania	SK	Slovakia
AT	Austria	FR	France	LU	Luxembourg	SN	Senegal
AU	Australia	GA	Gabon	LV	Latvia	SZ	Swaziland
AZ	Azerbaijan	GB	United Kingdom	MC	Monaco	TD	Chad
BA	Bosnia and Herzegovina	GE	Georgia	MD	Republic of Moldova	TG	Togo
BB	Barbados	GH	Ghana	MG	Madagascar	TJ	Tajikistan
BE	Belgium	GN	Guinea	MK	The former Yugoslav Republic of Macedonia	TM	Turkmenistan
BF	Burkina Faso	GR	Greece	ML	Mali	TR	Turkey
BG	Bulgaria	HU	Hungary	MN	Mongolia	TT	Trinidad and Tobago
BJ	Benin	IE	Ireland	MR	Mauritania	UA	Ukraine
BR	Brazil	IL	Israel	MW	Malawi	UG	Uganda
BY	Belarus	IS	Iceland	MX	Mexico	US	United States of America
CA	Canada	IT	Italy	NE	Niger	UZ	Uzbekistan
CF	Central African Republic	JP	Japan	NL	Netherlands	VN	Viet Nam
CG	Congo	KE	Kenya	NO	Norway	YU	Yugoslavia
CH	Switzerland	KG	Kyrgyzstan	NZ	New Zealand	ZW	Zimbabwe
CI	Côte d'Ivoire	KP	Democratic People's Republic of Korea	PL	Poland		
CM	Cameroon	KR	Republic of Korea	PT	Portugal		
CN	China	KZ	Kazakhstan	RO	Romania		
CU	Cuba	LC	Saint Lucia	RU	Russian Federation		
CZ	Czech Republic	LI	Liechtenstein	SD	Sudan		
DE	Germany	LK	Sri Lanka	SE	Sweden		
DK	Denmark	LR	Liberia	SG	Singapore		
EE	Estonia						

DIFFERENTIALLY ACTING OP DETOXIFYING SPONGES

Technical Field

This invention relates to materials, compositions, kits and methods for neutralizing, detoxifying or decontaminating equipment and/or personnel exposed to organophosphorus and organosulfur compounds.

Background of the Invention

Methods for decontamination, neutralization and removal of chemicals, such as organophosphorus and organosulfur (OP) compounds, herbicides and insecticides, are known in the art. However, the compositions and devices utilized in the prior art methods have undesirable properties, such as corrosiveness, flammability, toxicity, difficulty in making and storing, and limited shelf-life.

For example, DS2, a standard decontamination agent, comprises 70% diethylenetriamine, 28% ethylene glycol monomethyl ether, and 2% NaOH by weight. Although DS2 is effective, it is corrosive upon exposure to air. DS2 and any matter resulting from its use is classified and regulated as hazardous material. After an application, the DS2 must stand for 30 minutes before rinsing the treated area with water. Additionally, DS2 comprises a teratogen.

Some decontamination methods employ hypochlorite formulations which are corrosive and toxic and injure humans and sensitive tissues such as eyes. Other methods comprise incinerating the contaminated material and utilizing carbon filters to absorb the residual chemicals. Yet other methods utilize polymer beads or microemulsions which absorb the chemical and must be rinsed away. These methods are inherently dangerous, expensive and generate hazardous waste. Furthermore, as many of these compositions and compounds utilized degrade upon exposure to water and carbon dioxide, these compositions and compounds must be used the same day they are made.

Some *in vivo* methods employ cholinesterases in the presence of nucleophilic oximes to detoxify OP compounds. This enzyme bioscavenger approach is effective against a variety of OP compounds in rodents and nonhuman primates. For example, pretreatment of rhesus monkeys with fetal bovine serum acetylcholinesterase (FBS-AChE) or horse serum butyrylcholinesterase (Eq-BChE) confers protection against up to 5 LD₅₀ of soman, a highly toxic OP nerve agent. Although, the use of an enzyme as a single pretreatment drug for OP

toxicity is sufficient to provide complete protection to an individual subject, a relatively large (stoichiometric) amount of the enzyme is required to neutralize the OP compound *in vivo*. Therefore, OP/enzyme stoichiometry is increased by combining enzyme pretreatment with oxime reactivation so that the catalytic activity of OP inhibited FBS-AChE is rapidly and continuously restored, and the OP compound is detoxified.

Clearly, a need for better methods and devices for neutralizing, detoxifying, decontaminating and cleaning materials, equipment and personnel exposed to OP compounds exists.

Thus, OP detoxifying compounds, devices and methods thereof, which allow the safe, effective and convenient detoxification and quantitative and qualitative determination of highly toxic compounds not possible by the prior art, have been developed. These environmentally friendly compounds, devices and methods are disclosed hereinbelow.

Summary of the Invention

The present invention provides materials, compositions, kits and methods for neutralizing, detoxifying or decontaminating equipment and/or personnel exposed to OP compounds.

In one embodiment, the invention relates to a material comprising a mixture of enzymes and substrates for the removal, decontamination and neutralization of OP compounds including those directed against humans. The mixture of enzymes utilized comprises cholinesterases (ChEs) and/or OP hydrolases and reactivators, such as OP reacting compounds such as certain oximes like HI-6 and mono-bisquaternary oximes such as 2-PAM.

The material may comprise a flexible or rigid porous support. The porous support may be a polyurethane matrix or equivalent.

For example, the porous support may be a flexible sponge-like substance or like material, wherein the enzymes are secured by immobilization. Depending on the polyurethane prepolymer or substrate utilized, porous supports of varying degrees of flexibility and porosity may be obtained. The porous support may be formed into various shapes, sizes and densities, depending on need and the shape of the mold. For example, the porous support may be formed into a typical household sponge or a towelette. The preferred dimensions of the sponge are 1" x 2" x 8" to 2" x 4" x 8". The preferred dimensions of the towelette are 4" x 4" x 0.25" to 4" x 4" x 0.03125" to 14" x 14" x 0.0625". However, during large-scale synthesis, the dimensions of the initial immobilized enzyme product might be large. For example,

approximately 4 feet by 8 feet rolls could be produced and sized as appropriate and described above.

The sponge-like support would be preferable for use on surfaces, including natural, synthetic and biological surfaces such as equipment, laboratory hardware, devices, skin and other delicate membranes, where decontamination of a rough or irregular surface is desired or where the prior art decontamination materials are incompatible with human tissue. For example, the materials may be used to clean and decontaminate wounds as it is non-toxic and the immobilized enzymes will not leach into a wound. Therefore, the sponges could be used to decontaminate civilians contaminated by a terrorist attack at a public event.

If an object and/or area to be neutralized or decontaminated comprises cracks, crevices, porous or uneven surfaces, a foam-like support is suitable. Application of small quantities may be done with a spray-bottle or spray can with an appropriate nozzle. Further, foam may be selected so that it can be dispensed into the opening of sensitive equipment or an orifice of a subject, such as the ear canal. If a large area is contaminated, an apparatus that dispenses a large quantity of foam may be utilized.

The foam-like support may dissipate after a period of time like shaving cream or it may cure into a stable and flexible sponge-like support. The dissipating foam may be applied on living subjects. The foam, which cures, may be applied around an object and contain the contamination within the foam. Once the foam cures, the object may be handled and moved without further exposure to the hazardous chemical.

When necessary, the material may also comprise a rigid and porous support. The rigid material can be ground into a powder and added to lotions, soaps and other liquids for application. Likewise, the flexible material, supra, may be appropriately treated to render it suitable for use in lotions, soaps and other liquids.

The material may also be in the form of a filter for neutralizing, detoxifying or decontaminating gases such as air. Additionally, the material may be in a form suitable for use as clothing or linings of clothing. Furthermore, the material may be used to decontaminate water by placing the material in water and then removing it from the water.

In another embodiment, the material can be color-coded according to the specific substance it may neutralize, detoxify or decontaminate. The color or color scheme could be selected to indicate enzymatic concentration, activity and/or remaining shelf-life or range thereof.

The materials of the invention may be placed in containers to complete decontamination of the OP compounds on the materials.

Other embodiments include the methods of using the instant materials for the quantitative or qualitative determination of hazardous compounds such as OP compounds.

As disclosed herein, one of ordinary skill in the art will appreciate the various materials and their uses as contemplated by the inventors. All of these forms may be appropriately combined with carbon for further absorption of OP compounds. The carbon may be embedded or incorporated within the porous support of the material or the carbon may be a layer, filter or other to be used in conjunction with the material. Additionally, a slow release form, such as a dry capsule, pellet, liposome or other, of a reactivating compound such as HI-6 may be embedded or incorporated within the porous support of the material.

A preferred embodiment of the invention comprises a material wherein AChE and/or BChE are simultaneously immobilized with OP hydrolases on or within the porous support during synthesis of the material. Preferably, the enzymes are immobilized through covalent linkages. The enzymes may be of prokaryotic or eukaryotic origin. These enzymes may be recombinant. The enzymes may be contained within the cell or cell free. Other enzymes capable of hydrolyzing hazardous chemicals such as OP compounds may be employed. Likewise, enzymes such as triesterase may be used for the decontamination of pesticides in a similar manner as herein described. Preferred enzymes are those that may be reactivated or directly hydrolyzed OP compounds.

In another embodiment, the invention relates to the process of making a material, for the removal, decontamination or neutralization of hazardous chemicals such as OP compounds, comprising a mixture of enzymes immobilized on a porous support. In this embodiment, a mixture of enzymes and a prepolymer are gently and evenly mixed together with minimal degradation of the biotype component so that the resulting immobilized enzyme may effectively decontaminate, neutralize or detoxify an amount of an OP compound. The device utilized, folds the components into one another. This is a low shear process. During synthesis of the material by prior art methods, for example a mixing drill, the enzymes utilized are subjected to fluid forces or shear stress. Use of a device that gently folds the components into one another greatly reduces these fluid forces or shear stress, and is the preferred device for enzymes, specifically enzymes that are sensitive to the high shear forces of the drill mixing device. Additionally, use of additives such as surface-acting polymers, e.g. P-65, or low concentrations of glycerol protects against enzyme denaturation induced by shear forces. The

surface-acting polymers also gives appropriate consistency and absorbency of the solid support.

In a preferred process of making the material, a two chamber apparatus is utilized. One chamber contains a mixture of enzymes and the other chamber contains the prepolymer. The mixture of enzymes and the prepolymer are simultaneously extruded at a 1:1 ratio and mixed. Preferably, the mixture of enzymes and the prepolymer are rapidly and evenly extruded through a static mixing stator which gently and evenly mixes the enzymes and prepolymer. A preferred low shear device is a double chamber syringe and a static mixing stator typically used to mix viscous polyurethanes or epoxy glues. The size of the apparatus may vary depending on need. It may be pocketsize for use in the field by soldiers. Alternatively, the apparatus may be suitable for large-scale production and/or decontamination of a large objects or area. The low shear mixing device more than doubles the resultant AChE or BChE immobilized enzyme activity when compared to an identical mixture prepared with the high shear device.

The invention further relates to various materials, methods and devices for reactivating the enzymatic activity of the material. These materials, methods and devices will allow a person to use the decontamination material of the invention for several separate uses and/or for a single and continuous use, which would normally require several decontamination materials but for reactivation of the enzymatic activity of the immobilized enzymes. Additionally, these materials, methods and devices allow for complete decontamination and/or neutralization of excess OP compounds absorbed by the porous support but did not react with the immobilized enzymes. These methods and reactivation materials employ substrates and/or oximes, to reactivate the catalytic activity of the OP inhibited and immobilized enzymes.

The invention further relates to various materials and additives that are added to the embodiment to aid in the removal and decontamination of organophosphates from surfaces such as cracks, crevices, porous or uneven surfaces such as clothes and biological surfaces that readily absorb the organophosphates or pesticides such as skin. The additives are used in conjunction with the sponge material and may be incorporated within the porous support of the material. The additives may be in a dry or liquid form, and may be organophosphate solubilizing compounds such as triacetin or tetraglyme, or oximes, which both aid in decontaminating and reactivating enzymes.

Another embodiment of the invention relates to a variety of kits. These kits contain the sponge containing a plurality of enzymes needed for the decontamination of

organophosphorus and/or sulfur compounds. Also included may be materials which would facilitate or be deemed necessary for the decontamination process. Kits may also include polymeric materials and enzymes if the foam is transient in nature, e.g. the prepolymer, a stable enzyme mixture and a low shear apparatus for making an organophosphorus and/or organosulfur decontamination foam. These kits may also include the indicators for both quantitative or qualitative detection of OP compounds and means for transmitting results to a central collection point, e.g. computer, satellite uplinks, radio relays, handheld battery operated measuring devices, etc. For example, one may quantitatively analyze the OP compounds by using a handheld battery operated measuring devices and interfacing with a computer to calculate reaction rates which rates may be relayed to a central collection point. The kits may contain items to facilitate the use of the device, e.g. instructions, containers, test tubes, etc.

Description of the Drawings

This invention is further understood by reference to the drawings wherein:

Figure 1A illustrates the modeled surfaces of acetylcholinesterase, butyrycholinesterase and phosphotriesterase. Figure 1B illustrates the modeled surfaces of laccase.

Figure 2 shows a cured material.

Figure 3 schematically illustrates the specific reaction of the enzymes with prepolymer.

Figure 4 shows the linear correlation between the amount of BChE added during synthesis of the material and the amount of BChE in the final material.

Figure 5 shows the increasing amounts of BSA added during synthesis to a constant amount of AChE and TDI polymer.

Figure 6 illustrates that the materials maintained enzymatic stability for more than 3 years at 4°C and more than 12 months at 25°C and 45°C.

Figure 7 shows that the material maintained enzymatic activity after consecutive washes.

Figure 8 shows a substrate concentration dependent curve for soluble and polyurethane coupled AChE.

Figure 9 illustrates the pH range of soluble and immobilized AChE.

Figure 10 shows the relative activities of co-immobilized ChEs and OPHs.

Figures 11A and B show a version of a manual mixing gun and a disposable mixing stator.

Figure 12 schematically illustrates alternate schemes for detecting ChE activity.

Figure 13 is a model of a carbon electrode with immobilized ChE.

Figure 14 illustrates how F⁻ reverses the reaction between an OP compound and ChE.

Figure 15 illustrates how oximes may reactivate alkylphosphorylated ChE.

Figure 16A illustrates the enzyme activity of immobilized FBS-AChE. Figure 16B illustrates the enzyme activity of immobilized Eq-BChE.

Figure 17 represents inhibition of foam-immobilized FBS-AChE by DFP and reactivation by HI-6.

Figure 18 represents inhibition of foam-immobilized Eq-BChE by DFP and reactivation by TMB4.

Figure 19A shows about a 10-fold increase in K_m because a shift to the right is also observed in the immobilized (sponge) form when determined using the substrate paraoxon. On the other hand, Figure 19B shows little change in K_m for the substrate paraoxon, with OPAA (derived from *Alteromonas*).

Figure 20A shows the pH profile of soluble and immobilized choline oxidase. Figure 20B shows substrate concentration dependent curve for soluble and polyurethane coupled choline oxidase.

Figure 21A shows temperature profile of immobilized and soluble AChE. Figure 21B shows temperature profile of immobilized and soluble BChE.

Figure 22 shows that only at very high ratios of organophosphate (1000-fold molar excess) is the process of binding, reactivation, and detoxification not complete. However, fresh HI-6 can restore most of the original activity once again.

Figure 23 shows inhibition of AChE-sensor by the organophosphate MEPQ, which is not reversed by washing in water or buffer.

Figure 24A shows protection afforded by sponge with tetraglyme additive. Figure 24B shows protection afforded by sponge with HI-6 additive. Figure 24C shows protection afforded by sponge with 2-PAM additive.

Figure 25 illustrates the capacity of the resulting carbon sponge for binding methylene blue (a colorimetric indicator for activated carbon).

Figure 26A shows AChE-sensor activities after continuous incubation at 25°C at different pHs. Figure 26B shows BChE-sensor activities after continuous incubation at 25°C at different pHs. Figure 26C shows AChE-sensor activity after continuous exposure to Chesapeake Bay (Brackish) water at 25°C. Figure 26D shows AChE-sensor activity after

continuous exposure to Allegheny River (Fresh) water at 25°C. Figure 26E shows sensitivity of M272 ticket to aqueous conditions (Chesapeake Bay brackish water). Figure 26F shows sensitivity of M272 ticket to aqueous conditions (50 mM phosphate buffer, pH 8.0).


Figure 27A shows dose-dependent inhibition of immobilized AChE sensor and soluble AChE to the pesticide dichlorophos. Figure 27B shows dose-dependent inhibition of immobilized AChE (sensor) and soluble AChE to the organophosphate soman (GD).

Detailed Description of the Invention


Enzymes have been incorporated in hypo-based urethane foam during polymer synthesis. See U.S. Patent No. 4,342,834. Hypoprepolymer is synthesized from a reaction of polyether (or polyester) polyol with isocyanates in the presence of cross-linking agents. See Havens, P.L., *et al.*, *Ind Eng Chem Res* (1993) 32:2254-2258; U.S. Patent No. 4,137,200; LeJeune, K.E., *et al.*, *Biotechnology and Bioengineering* (1999) 20;62(6):659-665. Synthesis is initiated by bringing water molecules into contact with isocyanate groups present within the polyurethane prepolymer.

A two-step procedure occurs from this point. Isocyanates react with water to form an unstable carbonic acid, which in turn degrades to an amine yielding CO₂ that gives the porous support lift and enables it to rise. The amines readily react with isocyanate groups, leading to production of urea type linkages. Since the enzyme contains multiple functional groups, such as amines and hydroxyls that can react with isocyanates, the enzyme becomes an integral part of the porous support during synthesis. Significant quantities of enzyme can link to the porous support without disrupting the progress of polymer synthesis. The reaction occurring during the polymer synthesis is shown below.


1. CO₂ Evolution:




2. Urea Linkage:



3. Amine Group Enzyme Immobilization:



4. Hydroxyl Group Enzyme Immobilization:



The following list of enzymes and chemicals are examples of those suitable for use in the instant invention:

- Acetylcholinesterase (AChE);
- Butyrylcholinesterase (BChE);
- Pseudocholinesterase;
- Organophosphate hydrolases (OPH);
- Organophosphate acid anhydrase(OPAA);
- Phosphotriesterase;
- Pseudomonas diminuta* bacterial OPH (paraoxonase);
- Laccases;
- Pralidoxime chloride (2-PAM);
- 7-(methoxyphosphinyloxy)-1-methylquinolium iodide (MEPQ);
- Diisopropyl fluorophosphate (DFP);
- Acetylthiocholine iodide (ATC);
- S-butyrylthiocholine iodide (BTC);
- 5,5'-dithio-bis(2-nitrobenzoic acid) (DTNB);
- N,N'-trimethylene bis(pyridinium-4-aldoxime) dibromide (TMB4); and
- 1-(2-hydroxyiminomethyl-1-pyridinium)-1-(4-carboxyaminopyridinium)-dimethylether hydrochloride (HI-6).

By using mammalian cholinesterases such as FBS-AChE or Eq-BChE rather than Eel cholinesterase as is found in the M272 ticket (currently used to detect organophosphate compounds), the immobilized enzyme will display the same sensitivity to OPs that mankind is susceptible to now, or any new or novel OPs that might be produced in the future against mankind. Other enzymes capable of hydrolyzing hazardous chemicals such as OP compounds may be employed, for example laccase. Additionally, other OP hydrolyzing enzymes would ensure rapid and complete destruction of any toxic intermediates (for example, phosphoryloximes) that might be generated during the decontamination process.

The following examples are intended to illustrate but not to limit the invention.

Example 1Determination of Possible Enzyme Interference

As polyether prepolymer derived from tolyl diisocyanate (TDI), reacts most favorably with free aliphatic amines such as lysine and arginine present on the surface of the ChEs (or any protein) to become a permanent cross-linked part of the material, computer aided molecular modeling of the enzymes was performed to highlight the available amino groups on the surface of each enzyme, and to determine whether the coupling of these groups to a porous support would interfere with enzymatic function. This may be performed on every enzyme for which its crystal structure is known, or enzymes which may be modeled by homology.

Figure 1 A illustrates the modeled surfaces of acetylcholinesterase, butyrycholinesterase and phosphotriesterase and shows the lysine and arginine residues on the surface of the ChEs which are available for coupling to the prepolymer. This was generated by Insight II, molecular modeling software, by Biosym Technologies. Based on the molecular modeling, there are at least one lysine and 29 arginine water-accessible residues on the surface of FBS-AChE to couple to the porous support, while 26 lysine and 26 arginine residues were modeled for equine-BChE. The majority of the lysine and arginine residues were found on the backside of the ChEs, and only a few are found on the side of the enzyme where the catalytic site gorge is located. The rim and the catalytic site gorge opening of both AChE and BChE appeared to be essentially devoid of lysine and arginine. Therefore, coupling these enzymes to the porous support should have minimal effect on the entrance of substrate, inhibitors such as OPs, or reactivators such as oximes which includes mono-bisquaternary oximes, release of products of catalysis to and from the active site, and the kinetic rates of the enzymes. Similarly, a model of the surface of laccase (Figure 1 B) is shown with available residues to couple covalently to the prepolymer.

Example 2Synthesis of an Enzyme Bound Polyurethane Material

A typical synthesis of the material comprises mixing enzymes in phosphate buffer containing 1% (final concentration) surfactant with prepolymer. Polyether prepolymer derived from tolyl diisocyanate (TDI), Hypol prepolymer TDI 3000 (Hampshire Chemical, Lexington, MA), and Pluronic P-65 surfactant (BASF Specialty Chemicals, Parsippany, NJ) were used.

The 2-phase system is mixed and placed into a suitable mold and left to cure. Figure 2 shows a cured material which comprises a sponge-like support.

Figure 3 schematically illustrates the specific reaction of the enzymes with prepolymer. Synthesis begins when H₂O molecules react with the isocyanate groups present within the polyurethane prepolymer. Isocyanate reacts with the water to form an unstable carbonic acid, which degrades to an amine yielding CO₂. The CO₂ causes the polymer to rise and become porous, and simultaneously the amines readily react with the isocyanate groups leading to urea linkages.

Since the ChE contains amines that are on the surface and available to react with the isocyanate groups, they can become an integral part of the polyurethane support during synthesis. There is no significant entrapment of the enzyme in the material as found with cyclodextrins, or physical adsorption of the enzymes, as observed with activated carbon. The inclusion of a surfactant such as Pluronic P-65 at about 1% final concentration controls the final structure and absorption potential of the material.

To create a material comprising a porous polyurethane support, approximately 30 mL of 50 mM phosphate buffer, pH 8.0, containing P-65 surfactant buffer, was placed in a 600 mL plastic beaker. 3 to 5 mL of either purified FBS-AChE (7500 units) or purified Eq-BChE (5000 units) was added, followed by approximately 40 gm of Hypo 3000 prepolymer (tolyl diisocyanate). The two-phase system was mixed and the material was allowed to expand for 10 min, extruded from the container. The material was washed thoroughly with 50 mM phosphate buffer, pH 8.0, dried and stored in a zippered bag at 4°C for future use.

Example 3

Characteristics of Synthesized Material

Approximately 20-90% of the enzymes were covalently linked to the porous support through free amino- or hydroxyl groups. This was determined by the presence of enzyme in first and second washes of the material.

Since the enzymes can be attached at multiple points, they become a part of the cross-linked polymer support. The cross-linked polymer support imparts considerable stability to the bound enzymes. A large quantity of enzyme can be incorporated into a small polyurethane support, thereby rendering the cross-linked polymer support a highly effective material for decontamination.

A. Enzymatic Activity

Five samples of materials containing FBS-AChE and five samples of materials containing Eq-BChE, ranging in weight from 1 to 40 mg, were suspended in 2.8 mL of 50 mM phosphate buffer, pH 8.0, and assayed using the method of Ellman. See Ellman, G.L., *et al.*, (1961) *Biochem Pharmacol.* 7:88-95. A linear correlation was found between the weight of the sponge and enzyme activity for both FBS-AChE and Eq-BChE immobilizations. See Figures 16A and B. The linear correlation between the weight of the material and enzyme activity indicates a uniform immobilization of AChE or BChE throughout the material.

The material was washed with either 50 mM phosphate buffer, distilled water, or 10 mM ammonium bicarbonate without affecting substrate hydrolysis. Therefore, the mixing of prepolymer, surfactant, and enzyme *in situ* at 22°C yields a useful and effective material retaining about 50% of the original activity of soluble ChE.

B. Protein Loading Capacity

The material has a significantly higher loading capacity for ChEs such as BChE or AChE. The final activity of the BChE immobilized in the material could be increased by adding larger quantities of enzyme during synthesis. See Figure 4. When nonspecific protein (bovine serum albumin, BSA) was added to a constant amount of purified AChE, there was no reduction in ChE activity. See Figure 5. Thus, higher potency materials may be synthesized with additional proteins, enzymes and other ChEs. Additionally, materials effective against a diverse array of OP compounds may be readily synthesized by with combinations of *multiple* enzymes or a plurality of enzymes.

C. Enzymatic Stability

As illustrated by Figure 6, the immobilized ChE and OP hydrolase maintained enzymatic stability for more than 3 years at 4°C, and more than 12 months at 25°C and 45°C, respectively. If the material is frozen in liquid nitrogen, most of the original activity remains. TDI imparts remarkable stability to the immobilized ChE; about 50% of the original activity of the immobilized AChE and 20% of the activity of the immobilized BChE remained after 16 hours at 80°C, conditions under which the soluble enzymes would exhibit no activity. The ChE materials can be exhaustively dried under vacuum at 22°C and then rehydrated without loss of enzyme activity. When AChE or BChE materials were exhaustively washed and assayed for activity, the wash and assay cycle repeated more than twenty times over three

days, no decrease in activity occurred. *See Figure 7.* This indicates that the material may be used repeatedly.

These results also demonstrate that the ChEs are covalently cross-linked in the porous support and that the ChEs will not leach out to skin, water, or equipment. Therefore, once the immobilized enzymes bind an OP compound the OP is removed from the surface requiring decontamination.

D. Kinetic Constants

Table 1. Time-Dependent Inhibition of ChEs by MEPQ

ChE	Enzyme Form	Bimolecular rate constant ($M^{-1} min^{-1}$) \pm SD
FBS-AChE	soluble	$1.59 \pm 0.52 \times 10^8$
	coupled to sponge	$1.00 \pm 0.28 \times 10^8$
Equine-BChE	soluble	$4.15 \pm 0.78 \times 10^7$
	coupled to sponge	$4.21 \pm 2.00 \times 10^7$

The number of active sites of either the immobilized or soluble ChEs was determined by titration with the organophosphorus compound MEPQ, 7-(methylethoxyphosphinyloxy)-1-methylquinolinium iodide. The bimolecular rate constants for the inhibition of AChE material and BChE material and the respective soluble enzymes by MEPQ at 25°C showed that there was no significant difference between the soluble and covalently bound enzymes. *See Table 1.*

These results demonstrate that the immobilized and soluble forms of ChEs interact with the OP compounds similarly. Therefore, enzymatic activity assays which are generally available and known in the art may be used.

An initial rates method using a modified Ellman's assay was used to determine the parameters K_m , k_{cat} , and k_{cat}/K_m for immobilized and soluble AChE and BChE. The number of active sites of either the coupled or soluble ChEs was determined by titration with MEPQ. As shown in Table 2 and Figure 8 for AChE, the K_m values for the immobilized ChEs were about 10-fold greater than the corresponding soluble enzymes, and the k_{cat} values were less dramatically affected. The combined effects on affinity for substrate and k_{cat} resulted in approximately a 20 to 50-fold decrease in acylation (k_{cat}/K_m). Interestingly, while soluble BChE lacked substrate inhibition, immobilized BChE yielded substrate inhibition. These

results suggest that covalent binding of surface residues of ChEs to the porous support changed some properties of the active site region of the bound enzymes directly or indirectly.

Table 2. Kinetic parameters for soluble and polyurethane coupled ChEs.

Enzyme	Form	Substrate inhibition	K _m (mM)	K _{ss} (mM)	B	K _{cat} (min ⁻¹)	K _{cat} /K _m (M ⁻¹ min ⁻¹)
FBS-AChE	Soluble	yes	0.119	18	-	2.8 × 10 ⁵	2.5 × 10 ⁹
	immobilized	yes	1.090	22	-	5.9 × 10 ⁴	5.4 × 10 ⁷
Equine-BChE	Soluble	no	0.127	1.5	1.8	3.1 × 10 ⁴	2.4 × 10 ⁸
	immobilized	yes	1.200	16	-	1.8 × 10 ⁴	1.5 × 10 ⁷

Determined in 50 mM phosphate, pH 8 at 25°C using an initial rates method.
 Calculated from V_{max} and the active site concentration of ChE that was determined by MEPQ titration.
 Values were calculated² using modified Haldane equations, and the special case where b=0. The best fit between the two was determined using an F test, where significance was defined as p<0.05.

Generally, immobilized cholinesterases or OP hydrolyzing enzymes exhibit between the same to 10 fold greater K_m values than the corresponding soluble enzymes. In addition to the cholinesterases, OPH (derived from *Pseudomonas diminuta*, Figure 19A) shows about a 10-fold increase in K_m because a shift to the right is also observed in the immobilized (sponge) form when determined using the substrate paraoxon. On the other hand, OPAA (derived from *Alteromonas*, Figure 19B), shows little change in K_m for the substrate paraoxon.

K_m Determination of immobilized and soluble choline oxidase:

The K_m of the soluble and immobilized forms (sponge) of choline oxidase are observed to be similar since there is little shift in the substrate curve, as shown by Figure 20B, indicating that this enzyme is not only very suited to immobilization, but also for co-immobilization with the cholinesterases. The observed K_m for soluble and sponge are 2.5 and 6.7 mM, respectively.

E. pH of Soluble and Immobilized Enzymes

The pH profiles of immobilized and soluble AChE are identical and the enzymes exhibit activity throughout the broad pH range of 7-8.5. See Figure 9. Since the pH profiles of soluble cholinesterases, OP hydrolases and choline oxidases have optimal activities in this same pH range, the materials may be optimized and diversified by employing a plurality of these multiple enzymes immobilized on or within a porous support.

Figure 20A: The pH profile of soluble and immobilized choline oxidase. Compare with Figure 9, the pH profile of soluble and immobilized acetylcholinesterase

Temperature Dependent Activity of Soluble Cholinesterases and Sensor (Immobilized) Cholinesterases

The sensors containing immobilized AChE or BChE exhibited almost identical temperature dependent activity when compared to their soluble counterparts (Figures 21 A and B). However, as shown in Figure 6, the immobilized enzymes are more resistant to the denaturing conditions of elevated temperatures for extended periods, while the soluble enzymes are not. The immobilized enzymes are also resistant to freezing in liquid nitrogen. These profiles indicate that at cold temperatures, the sensors could be warmed by body heat or an external source to increase the reaction rates.

Example 4

Immobilization of a Plurality of Enzymes

ChEs were co-immobilized with bacterial OP hydrolase (OPH_B) and/or rabbit serum OP hydrolase (OPH_R). There was no reduction in the enzymatic activities of AChE or BChE co-immobilized with OPH as compared to the enzymatic activities of each of these enzymes individually immobilized. *See* Figure 10. Additionally, there was no reduction in the enzymatic activity of co-immobilized OPH. Therefore, a plurality of enzymes, which each enzyme differentially reacts with various OP compounds, may be selected and utilized in a material to create a decontamination material effective against a wide range of OP compounds.

Example 5

Rapid Mixing Synthesis

By utilizing a method of syntheses modified from the adhesive industry (CPA, Greenville, RI 02828) shear forces which decrease enzymatic activity are reduced. *See* Figures 11A and B. In this method, the enzyme is not in an organic buffer as required in some immobilization techniques. This results in less air-induced shearing, thereby maintaining enzymatic activity. This method is also simple to conduct, rapid and reproducible. The low shear mixing device more than doubles the resultant AChE and/or BChE immobilized enzyme

activity when compared to an identical mixture prepared with the high shear device such as a mixing drill. See Table 3.

Table 3	
Technique	AChE Activity U/mg
High shear mixing drill	0.100
Low shear 2-chamber device	0.270

Example 6

Inhibition of Immobilized FBS-BChE with DFP and Reactivation with HI-6

100 mg samples of immobilized FBS-AChE were incubated with varying concentrations of DFP in 2 mL of 50 mM phosphate buffer, pH 8.0, for 1 hour at 25°C. In parallel experiments, 1 mM HI-6 was added to the same amount of material and DFP. Residual DFP in the samples was measured by adding a 0.5 mL aliquot of the reaction mixture to 0.5 mL of a fresh 1 U/mL solution of FBS-AChE, incubating for 1 hour, and assaying 10 µl aliquots using the Ellman procedure. The results are shown in Figure 17.

The inhibition of FBS-AChE activity by DFP was proportional to the stoichiometric amount of DFP added to the foam suspended in buffer. The presence of 1 mM HI-6 nearly completely prevented enzyme inhibition by DFP. This indicates that immobilized FBS-AChE may be repeatedly reused after reactivating the enzyme with an oxime solution such as HI-6. Figure 15 illustrates how oximes may reactivate alkylphosphorylated ChE activity.

Example 7

Inhibition of Immobilized Eq-BChE with DFP and Reactivation with TMB4

50 mg samples of immobilized Eq-BChE were incubated with varying concentrations of DFP in 2 mL of 50 mM phosphate buffer, pH 8.0, for 18 hours at 25°C. In parallel experiments, 1 mM TMB4 was added to the same amount of material and DFP. Residual DFP in the samples was determined by adding a 0.5 mL aliquot of the reaction mixture to 0.5 mL of a fresh 1 U/mL solution of Eq-BChE, incubating for 1 hour, and assaying 10 µl aliquots using the Ellman procedure.

TMB4 was used as a reactivator instead of HI-6, since TMB4 is a more efficient reactivator of inhibited Eq-BChE than is HI-6. These results are shown in Figure 18. As in Example 6, the foam-bound Eq-BChE may be repeatedly reused after reactivating the enzyme

with an oxime solution such as TMB4. Figure 15 illustrates how oximes may reactivate alkylphosphorylated ChE activity.

Example 8

Determination of Enzymatic Activity

Figure 12 illustrates a variety of methods for determining presence of immobilized AChE and/or BChE and/or the effectiveness of a material. In the following examples, the material is first exposed to OP compounds and then qualitative and/or quantitative analysis may be performed. Qualitative analysis may be visually performed by utilizing visible chromogens and/or chemiluminescent chromogens. Quantitative analysis may be performed by using handheld devices, which measure amounts of fluorescence, chemiluminescence, or visible chromogens. Alternatively, the amount of H₂O₂ generated may be used to determine the effectiveness of the material.

For evaluating the presence of immobilized AChE and/or BChE in a material, a modified Ellman method in an aqueous phosphate buffered environment containing either acetylthiocholine for AChE or butyrylthiocholine for BChE as substrates may be conducted. If immobilized AChE and/or BChE are present, an intense yellow color will result from the reaction and may be spectrophotometrically monitored at 412 nm. For determining the presence of immobilized OP hydrolases in a material, diethyl p-nitrophenylphosphate may be used as the substrate and the reactions may be monitored at 500 nm. The Ellman and OP hydrolase assays produce a yellow chromogen if the enzyme is present, and no color if the enzyme is absent. Alternatively, 2,6-dichloroindophenyl acetate may be used as the substrate will remain a red color if the enzyme is absent and will turn blue (2,6 dichloroindophenylate) if the enzyme is present.

For fluorescent determination of the presence of an immobilized enzyme, the substrate may be either 1-methyl-7-acetoxyquinolinium iodide. In the presence of an enzyme, a highly fluorescent compound, 1-methyl-7-hydroxyquinolinium iodide, will result, i.e. 405 nm/em 505 nm. Alternatively, fluorogenic maleimide *N*-(4-(7-diethylamino-4-methyl-coumarin-3-yl)phenyl)-maleimide which condenses with the thiol formed from acetyl- or butyryl-thiocholine hydrolysis by ChEs, may indicate the presence of the immobilized enzyme, i.e. 390 nm/em 473 nm.

For chemiluminescent analysis, a ChE substrate and or benzoylcholine, choline oxidase, peroxidase and luminol are utilized.

Electrodes may be used to detect the presence and effectiveness of a plurality of immobilized enzymes in a material with the use of a plurality of substrates such as ChEs, choline oxidase, and peroxidase.

Example 8

Inhibition of Immobilized AChE with the Organophosphate MEPQ and Detoxification of the MEPQ and Reactivation of the Immobilized Enzyme in the presence of HI-6

50 mg samples of immobilized acetylcholinesterase were incubated with varying concentrations of MEPQ in 2 mL of 50 mM phosphate buffer, pH 8.0 at 25°C for 1 hr. In the absence of oxime HI-6, the sponge soaks up the MEPQ and is inactivated. Addition of HI-6 reactivates the sponge's activity, and the MEPQ is detoxified, and most of the original activity of the sponge returns. Only at very high ratios of organophosphate (1000-fold molar excess) is the process of binding, reactivation, and detoxification not complete. However, fresh HI-6 can restore most of the original activity once again. See Figure 22.

Example 9

50 mg samples of immobilized FBS-AChE were incubated with twice the stoichiometric ratio of the organophosphate MEPQ in 2 mL of 50 mM phosphate buffer, pH 8.0 for 10 min or 30 min at 25°C. Within the shortest time period measured, the sensor indicates inhibition. Furthermore, the sensor can be washed in water or buffer without reversing the inhibition by the organophosphate. See Figure 23.

Example 9

Diversified Material Comprising Multiple Immobilized Enzymes

Materials comprising cholinesterases, OP hydrolases, and enzymes which hydrolyze other OPs may be covalently immobilized on, within or encapsulated in a porous support to form a material for neutralizing, detoxifying or decontaminating equipment and/or personnel exposed to a diverse array of OP compounds. For example, since serum OP hydrolase from rabbit exhibits high activity with sarin, but not with soman, rabbit OPH and OPH from another source may be co-immobilized within a porous support to form a material useful for neutralizing, detoxifying or decontaminating both sarin and soman.

Additionally, since the enzymes from several species of halophilic and *Alteromonas* bacteria have considerable variation in enzymatic activity towards organophosphorus

compounds, a plurality of these enzymes may be immobilized on or within the porous support. For example, since OPH from *A. undi* displays higher enzymatic activity against soman with respect to sarin and/or tabun, OPH from *A. undi* and OPH from another source having high activity against sarin and tabun may be used. Furthermore, a plurality of OP hydrolases, ChEs, laccases and/or mediators of laccases and mutations thereof may be used for making a material effective against a broad range of OP compounds.

Tables 4 and 5 outline a few enzymes that may be used against given OP compounds.

Table 4. Relative activity of enzyme

OXYGEN	AChE or BChE	Rabbit OPH	<i>Alteromonas undi</i>	Laccase
Sarin	Inhibited	++	+	-
Soman	Inhibited	-	+++	-
Tabun	Inhibited	-	+	-
VX	Inhibited	-	-	++
-, not tested or not hydrolyzed				

Table 5. Potential multiple immobilized enzymes

Enzyme type and origin	Distinguishing characteristics	References
AChE, BChE	Inhibited by OPs	1, 2
Laccase	Hydrolyzes VX preferentially with mediator	21
OPH Human serum	Hydrolyses tabun, VX poorly	13
Rabbit serum	Hydrolyses sarin preferentially	32
<i>Pseudomonas</i>	Hydrolyses G agents	33
<i>Alteromonas undi</i>	Hydrolyses soman preferentially	17
Squid	Hydrolyses tabun, VX poorly	34

Example 10

Additives to the Sponge to Improve Decontamination of Soman (GD) Contaminated

Skin of Guinea pigs

Sponges approximately 1 ½ x 2 ½ x 1/4 " (HxLxD) contained 9.0 mL of additive and a second sponge contained 4.5 mL of additive. Each guinea pig was wiped with the first sponge and then the second sponge after soman (GD) exposure. Survival of the guinea pigs was determined after 24 hours, and the protective ratio determined. The protective ratio is the ratio of the LD₅₀ of the sponge containing an additive to the LD₅₀ of soman in the absence of sponge. Thus, the higher the LD₅₀, then the higher the protective ratio and the more effective the sponge combination is for decontamination of guinea pig skin and protecting the animal from the organophosphate. The sponge was compared to the M291 kit, the currently used

decontamination kit fielded by the US Army. As shown in the table, the sponges provide 4 to 5-fold better protection than the M291 kit.

Figure 24A shows the protection afforded by tetruglyme; Figure 24B the protection afforded by HI-6, and Figure 24C the protection afforded by 2-PAM. The number on the top of each bar shows the number of guinea pigs evaluated at the indicated dose of soman (GD). For reference, the LD₅₀ of soman on guinea pigs without any effort to decontaminate is shown by the label "GP", while the protection offered by the M291 kit is shown by "M291". Other additives to the sponge such as triacetin also afforded some additional protection compared to the M291 kit.

Additive to sponge	LD ₅₀	Protective Ratio
HI-6 (oxime, 50 mM)	79	8.0
2-PAM (oxime, 50 mM)	76	7.7
Tetruglyme (30%)	88	8.9
Reference values		
M291 decon kit	17.7	1.8
Soman alone	9.9	--

Example 11

Remote Quantitative and Qualitative Analysis of OP Compound.

As an OP inhibited enzyme is not readily reversible and the enzyme is immobilized, the material may be transported from the test site to another site to be analyzed for the presence and amount of given OP compounds. Additionally, the material may be left at a site to monitor OP compounds for a period of time. Since the OP inhibited enzyme is not readily reversible, interfering compounds and compositions may be removed from the material either at the test site or at a different location. Furthermore, the analysis need not be conducted immediately or soon after sampling.

A. Fluoride-Induced Release of OP

High concentrations of F⁻ cause the release of OP compound complexed to the inhibited ChE immobilized on the material. See Figure 14. This results in a soluble phosphofluoridate, which is specific for the OP compound present. The phosphofluoridate may be identified and quantified by gas chromatography and further verified with mass spectrometry in order to determine the original OP compound. Specifically, a material

containing the inhibited ChE and washed free of interfering compounds is acidified to pH 4 and incubated with 2M potassium fluoride. The solution is then extracted with a C₁₈ SepPak (Waters Associate, Milford, Mass.). The OP compound is eluted and identified by gas chromatography and mass spectrometry. Most of the OP agents of interest may be identified and discriminated from OP pesticides. In this example, the samples need not be frozen in order to be tested for OP compounds at a later date since the material is extremely resistant to mechanical stress, harsh chemical conditions, and extreme and varying temperatures.

B. Enzymatic Digestion

As an alternative procedure, enzymatic digestion may be used for post-exposure identification of OP compounds. The OP compounds may be released from the enzymes immobilized on or within the porous support and digested with 1M Tris buffer, pH 10, and alkaline phosphatase. Then the high molecular weight products may be concentrated, dissolved in a solution of pyridine and trimethylsilylation agents. The samples can then be analyzed by gas chromatography and mass spectrometry.

Example 12

Activated Carbon Containing Sponge

0.5-1 grams of activated carbon was added to about 4 mL of the prepolymer prior to mixing with acetylcholinesterase (5 mL of Electric eel, in 50 mM pH 8.0 phosphate buffer with 1% Pluronic P-65) to produce an acetylcholinesterase immobilized carbon sponge. The addition of carbon did not interfere with the immobilization of the enzyme, as shown in the table. The capacity of the resulting carbon sponge for binding methylene blue (a colorimetric indicator for activated carbon) is illustrated in Figure 25. Therefore, comparison of the sponge with activated carbon to the sponge lacking activated carbon demonstrates that it can bind about 2-fold more methylene blue at less than saturating concentrations.

Activities of Sponges and Activated Carbon		
Type of Sponge	Relative Activity (% control in absence of carbon)	Relative Activity to absorb methylene blue
Electric eel AChE sponge	100 %	1X
Electric eel AChE sponge with Activated Carbon	108 %	2X
Activated Carbon not in the sponge	---	13X

Example 13On-Site Qualitative and Quantitative Determination of OP Compounds

Qualitative and quantitative determination of OP compounds may be conducted on-site by utilizing a plurality of indicators encapsulated and embedded on or within the porous support. The indicators may be encapsulated in a structure which is easily broken by mild pressure, such as a liposome or a tiny crushable packet. Thus, one may use the material to decontaminate or detoxify an area then squeeze the material to release the indicator from the tiny crushable packet or liposome. The change in color will indicate the amount of or type of OP compound the material decontaminated or detoxified.

Example 14Multiple uses of the Differentially Acting Material

A sponge of desired size with immobilized enzymes, e.g. ChEs, choline oxidase and peroxidase, may be synthesized with built-in carbon electrodes. *See Figure 13.* The electrodes would be immersed within the enzyme containing sponge, and would reflect the activity of the enzyme in the surrounding area. The carbon electrode may be plugged into a hand-held and battery operated electrochemical detector. When substrate is added, e.g. acetylthiocholine or acetylcholine, the electrode will yield a response if the sponge is not exhausted and can detoxify additional OPs. In this manner, the sponge will act as a detoxifying sponge and as a biosensor in an alternative mode.

Additionally, the carbon electrodes may be inserted into various areas of a cured foam. In the event of a terrorist attack, and in the presence of substrate, the carbon electrodes could convey information about the OP compound in the environment to a central collection point.

Alternatively, the foam could be sprayed with substrate, which may be colorimetric, chemiluminescent or fluorescent, so that a change in foam color, i.e. chemiluminescent or fluorescent, would indicate that the foam is active and that there is no leakage of OP compound or pesticide. Lack of color change would indicate such things as a defective indicator, not enough enzyme was administered, the OP compound was not sufficiently contained by the foam, defective enzyme was utilized or the oxime was consumed. Therefore, the location where color is absent would indicate the need to spray additional or different foam. A positive control, i.e. biosensor, may be used to determine whether or not the indicator is defective.

The sponge containing immobilized enzyme could be used to soak up the OP or pesticide and placed in a plastic bag to complete decontamination of the chemical toxin. After a period of time, substrate in crushable vials or packets included in the plastic bag could be released by manual crushing. A strong color development would indicate effective detoxification. Several crushable vials or packets may be included so that the completion of decontamination could be tested several times. For example, if after the first test, an insufficient color change would show that insufficient time had elapsed to complete decontamination. The sufficiency of decontamination could be rechecked at a later time by simply crushing another vial. As several vials were originally included in the bag, reopening the bag is unnecessary and therefore avoids further exposure to the OP compound or insecticide. Further, if the substrate were a chemiluminescent, the decontamination may be evaluated in the dark without a power source.

The material containing multiple enzymes may be synthesized in a shape suitable to allow water to flow through it or around it, such as in a column or a chamber in order to bind all the OPs. A portion of the material could be removed and placed with a crushable packet to release substrate. Color development would indicate detoxified water. The material could be reused. It would not, most likely, have reactivating oxime because then the oxime would leach to the drinking water.

Again, lack of color change would indicate such things as a defective indicator, not enough enzyme was administered, defective enzyme was utilized or the oxime was consumed. Therefore, lack of color change would indicate the need to utilize an additional or a different sponge. A positive control, i.e. biosensor, may be used to determine whether or not the indicator is defective. Additionally, if the indicator is not defective and the sponge did not develop color, it could be reactivated with oxime for other detoxifying purposes.

Example 15

Long-term Sensing of Aqueous environments for Organophosphates

A significant advantage of the immobilized enzymes is that they are covalent immobilized permanently within the polyurethane matrix. This affords the sensors with the following properties that are absent in the soluble state of the enzymes or when the enzymes are non-covalently attached to papers, tickets, or other indicating strips.

A. Ability to Retain Activity after Continuous Incubation at 25⁰C at different pHs

The activity of immobilized AChE and BChE enzymes after 2 months at 25⁰C in buffers at pHs from 4.0 to 10.5 are shown in Figure 26A and 26B, respectively. Even after more than a month in solution without sterilization, both ChE sensors retained most of their original activity at pHs between 6-8, and significant activity was only lost at the extremes of pH4 and 10.5. The loss of activity at the extreme pHs is not unexpected since it is known that these conditions cause irreversible denaturation of the soluble enzymes. However, note that for short periods of less than a few days, 50% or more of the original activity of the immobilized enzymes remained, while the soluble enzyme would have been completely denatured. These results demonstrate that the ChEs are suitable for long-term (days to many weeks) detection of OPs. For instance, the sensor could be left at a remote location and retrieved at a later date.

B. Ability to Retain Activity after Continuous Incubation in Natural Water Sources at Ambient (25⁰C) Temperatures

Additional evidence that the AChE sensor retains activity for extended periods in the environment is observed in Figure 26C (Exposure to Brackish Water, obtained from the Chesapeake Bay, Aberdeen, MD) and Figure 26D (Exposure to Fresh Water, obtained from the Allegheny River, PA). Most of the original activity of the sensor remains even when exposed to water for over 1 month. The immobilized enzyme was also resistant to natural microbiological flora and fauna that could degrade the enzyme since autoclaved water was not more stable than untreated water. Taken together, these results demonstrate the long-term sensing potential of these immobilized enzymes.

C. Comparison of the M272 ticket with example A and B, above

The M272 ticket (Available from Truetech, Inc.) is the currently fielded ticket for sensing organophosphates in aqueous solutions. The ticket contains non-covalently bound Eel cholinesterase. In contrast to the 1-2 months that the immobilized AChE and BChE sensors can retain activity even after continuous exposure to natural water sources, varying pH, temperature (up to years), etc, the M272 ticket loses more than 80% of its activity after exposure to Chesapeake Bay water (Figure 26E) or a buffer (50 mM phosphate buffer, pH 8.0 (Figure 26F) after only 5 minutes of exposure. Therefore, while the immobilized enzymes are suitable for long-term monitoring of the environment including water, in contrast, the M272

ticket is not suitable for even short-term monitoring of water sources for organophosphorus compounds.

Example 16

Enzyme Coupling Prior to Formation of the Material.

The enzymes may be coupled together prior to formation of the material by means known in the art to form a cross-linked enzyme complex. *See e.g.* Hashida, S., Imagawa, M., Inoue, S., Ruan, K.-h, and Ishikawa, E. (1984) J. Applied Biochem. 6, 56-63 and Samaoszuk, M.K., Petersen, A., Lo-Hsueh, M., and Rietveld, C. (1989). (A peroxide-generating immunoconjugate directed to eosinophil peroxidase is cytotoxic to Hodgkin's disease cells in vitro.), Antibody Immunocon. Radiopharm. 2(1), 37-46.

For example, AChE may be conjugated to choline oxidase with one of the various cross-linkers and methods known in the art. Therefore, AChE and choline oxidase would be in close proximity so the product of AChE hydrolysis, choline, would fall right next to the choline oxidase to produce H₂O₂. This type of enzymatic cascade would provide more efficient coupling and a faster and more sensitive response. In addition, because of the proximity of choline oxidase, *i.e.* choline oxidase to AChE, the ratio of choline oxidase to AChE may be reduced. More than two different enzymes may be utilized.

The cross-linker utilized may be a multifunctional cross-linking agent. A wide variety of cross-linking agents are available from commercial suppliers, *i.e.* Pierce (Rockford, IL). These multifunctional cross-linking agents may comprise varying lengths of spacer arms to ensure that the bridge between the linked enzymes is an appropriate length for maintaining independent enzyme structure, function and activity. Typically, this would be a length of about 4-8 angstroms. However, the length may be up to 16 angstroms. Some cross-linking sites must be available for coupling the conjugated enzymes to the prepolymer. The cross-linking may be performed in the same buffer as used for the prepolymer reaction as explained in Example 2. The enzyme conjugate is then mixed with a prepolymer, as in Example 2, to form a polymeric material.

Example 17Sensitivity of Soluble and Immobilized Mammalian AChE to Pesticide (Dichlorophos) and Organophosphate (Soman, GD)

AChE sensor and soluble AChE were exposed to dilutions of dichlorophos in 2.5 mL of 50 mM phosphate buffer for 5 minutes, and then the activity of the enzymes in soluble form and immobilized sensor were determined. As shown in Figure 27A, the sensitivity of the immobilized sensor and soluble enzyme exhibited very similar EC₅₀ values, however the slope for the sponge was about 20% less than the soluble enzyme. These results indicate that the AChE-sponge was slightly less sensitive to inhibition by the pesticide than the soluble mammalian enzyme.

Similar results were observed for the inhibition of AChE sensor (immobilized enzyme) and the soluble acetylcholinesterase. Figure 27B demonstrates that when the enzymes are exposed to soman for 5 minutes and then inhibition of the enzyme determined, the curves indicating loss of enzyme activity by soman exposure are not significantly different. Thus, in the absence of soman, there is color development and enzyme activity (100% level) while at 30 pg of soman, little color reaction develops and activity is less than 20% of the control level.

References Cited in Table 5

- (17) DeFrank, J.J., Beaudry, W.T., Cheng, T-C., Harvey, S.P., Stroup, A.N., and Szafraniec, L.L. Screening of halophilic bacteria and *Alteromonas* species for organophosphorus hydrolyzing enzyme activity. *Chem.-Biol. Interactions* 87:141-148 (1993).
- (33) Donarski W.J., Dumas D.P., Heitmeyer D.P., Lewis V.E., Raushel, F.M. Structure-activity relationships in the hydrolysis of substrates by the phosphotriesterase from *Pseudomonas diminuta*. *Biochemistry* 28:4650-5 (1989).
- (32) Furlong, C.E., Richter, R.J., Chapline, C. and Crabb, J.W. Purification of rabbit and human serum paraoxonase. *Biochemistry*, 30:19133-10140 (1991).
- (13) Gan, K.N., Smolen, A., Eckerson, H.W., La Du, B.N. Purification of human serum paraoxonase/arylesterase. Evidence for one esterase catalyzing both activities. *Drug. Metab. Disp.* 19:100-106 (1991).
- (34) Hoskin, F.C., Roush, A.H. Hydrolysis of nerve gas by squid-type diisopropyl phosphorofluoridate hydrolyzing enzyme on agarose resin. *Science* 215:1255-7 (1982).
- (2) Maxwell, D.M., C.A. Castro, D.M. De La Hoz, M.K. Gentry, M.B. Gold, R.P. Solana, A.D. Wolfe, B.P. Doctor. Protection of rhesus monkeys against soman and prevention of performance decrement by treatment with acetylcholinesterase, *Toxicol. Appl. Pharmacol.* 115 44-49 91992).
- (21) Personal Communication, Dr. Gabriel Amitai, Israel Institute for Biological Research,

Ness Ziona, Israel.

(1) Taylor, P., Anticholinesterase agents, in: A.G. Gilman, T.W. Rall, A.S. Nies, P. Taylor (Eds.), *The Pharmacological Basis of Therapeutics*, Pergamon, New York, pp. 131-149 (1990).

Incorporation by Reference

To the extent necessary to understand or complete the disclosure of the present invention, all publications, patents, and patent applications mentioned herein are expressly incorporated by reference therein to the same extent as though each were individually so incorporated.

Claims

1. A polymeric sponge or foam for the removal, decontamination, detoxification and/or neutralization of a diverse array of organophosphorus and/or organosulfur compounds comprising a plurality of enzymes or a cross-linked enzyme complex immobilized on a polymeric porous support, said plurality or said cross-linked enzyme complex comprises multiple-enzymes selected from the group consisting of: acetylcholinesterase (AChE), butyrylcholinesterase (BChE), triesterase, pseudocholinesterase, choline oxidase, peroxidase, organophosphate hydrolase (OPH), phosphotriesterase, paraoxonase, laccase and other OP hydrolyzing enzymes.
2. The polymeric sponge or foam of claim 2 wherein said porous support comprises polyurethane.
3. The polymeric sponge or foam of claim 1 further comprising carbon embedded or integrated on or in the porous support.
4. The polymeric sponge or foam of claim 1 further comprising an indicator for measuring the capacity of the sponge for further use.
5. The polymeric sponge of claim 4 wherein the indicator is fluorescent, chemiluminescent or visible chromogen or is an electrode.
6. The polymeric sponge or foam of claim 1 further comprising a reactivation compound, material or device embedded or integrated on or in or attached to the porous support.
7. The polymeric sponge or foam of claim 6 wherein said reactivation compound, material or device comprises HI-6, TMB4, or mono-bisquaternary oximes.
8. A method of making a polymeric sponge or foam for the removal, decontamination, detoxification and/or neutralization of a diverse array of organophosphorus and/or organosulfur compounds comprising immobilizing a plurality of enzymes or cross-

linked enzymes on or in a polymeric porous support, said plurality of enzymes or cross linked enzymes comprises multiple enzymes selected from the group consisting of: acetylcholinesterase (AChE), butyrylcholinesterase (BChE), triesterase, pseudocholinesterase, choline oxidase, peroxidase, organophosphate hydrolase (OPH), phosphotriesterase, paraoxonase and OP hydrolyzing enzymes so as to decontaminate, detoxify and/or neutralize the diverse array of organophosphorus and/or organosulfur compounds.

9. The method of claim 8 wherein the step of immobilizing comprises mixing said plurality or said cross-linked enzyme complex with a polyurethane prepolymer.

10. The method of claim 9 wherein said polyurethane prepolymer comprises a diisocyanate.

11. The method of claim 10 wherein the diisocyanate is tolyl diisocyanate.

12. The method of claim 9 wherein equal parts of said plurality or said cross-linked enzyme complex and said polyurethane prepolymer are simultaneously mixed.

13. The method of claim 12 wherein the step of mixing is conducted with an apparatus having a first chamber and a second chamber.

14. The method of claim 13 wherein said first chamber contains said plurality or said cross-linked enzyme complex and said second chamber contains a polyurethane prepolymer.

15. The method of claim 14 wherein said mixing comprises extruding equal parts of said plurality or said cross-linked enzyme complex and said polyurethane prepolymer rapidly and evenly through a static mixing stator.

16. A polymeric sponge or foam for the removal, decontamination, detoxification and/or neutralization of

a diverse array of organophosphorus and/or organosulfur compounds made by the method of claim 8.

17. A method of reactivating a polymeric sponge or foam of claim 1 comprising contacting said polymeric sponge or foam with at least one compound selected from the group consisting of: HI-6, TMB4, and mono-bisquaternary oximes.

18. The polymeric sponge or foam of claim 1 wherein said polymeric sponge or foam is color-coded according to the specific chemical the polymeric sponge or foam neutralizes, detoxifies or decontaminates; the enzymatic concentration, activity or remaining shelf-life of said sponge or said foam; or the presence of the chemical neutralized, detoxified or decontaminated.

19. A kit for the removal, decontamination, detoxification and/or neutralization of an array of hazardous chemicals comprising the polymeric sponge or foam of claim 1.

20. A kit according to claim 19 further comprises a compound or compounds for the reactivation of the enzymes in an amount sufficient to displace covalently attached organophosphorus compounds from the enzyme active site by nucleophilic attack.

21 A method for decontaminating a surface where one or more hazardous chemicals may be present comprising contacting the surface with the polymeric sponge or foam of claim 1.

22. A method for decontaminating a surface where one or more hazardous chemicals may be present comprising contacting the surface with the polymeric sponge or foam of claim 4.

23. The method of claim 21 or 22 further comprising measuring the capacity of the sponge for further use.





Figure 1A Modeled surfaces of ChEs and triesterase. The top row shows a view of the front of the enzymes with the lip of the active site gorge outlined with a dotted line in the center. The bottom row shows the backside of the enzymes (180° rotation). The Lysine and Arginine residues on the surface, which are potential coupling sites to the polymer, are shaded dark in both the top and bottom row.

Figure 1B

Similarly, a model of the surface of laccase is shown with available residues to couple covalently to the prepolymer (top, front of enzyme; bottom, backside of enzyme).






Figure 2. Final product: FBS-AChE sponge






**TDI prepolymer functional group****1. Aqueous Initiation of Polymerization****2. Amine Formation and CO₂ Evolution (foaming)****3. Prepolymer Crosslinking****4. Covalent ChE Incorporation at Aliphatic Amino Group(s)****polyurethane crosslinked ChE**

Figure 3




Figure 4. A linear correlation was observed between the amount of BChE added to the prepolymer during synthesis and the amount of BChE activity observed in the final sponge.




Figure 5. Increasing amounts of BSA were added during synthesis to a constant amount of AChE and TDI polymer




Figure 6. Stability of AChE (top) and BChE (bottom) sponges at various temperatures.




Figure 7. An AChE-sponge was alternately washed with phosphate buffer and assayed for activity. This procedure was carried out for three days. Similar results were observed for BChE-sponge.




Figure 8. Substrate concentration dependent curve for soluble and polyurethane coupled AChE.




Figure 9. pH profile of soluble and immobilized acetylcholinesterase.




Figure 10. Co-immobilization of ChEs and OP hydrolases.




Figure 11A




Figure 11B

Figure 11A shows a version of a manual mixing gun and Figure 11B shows a disposable mixing stator. Complete mixing of the enzyme in aqueous solution and the viscous prepolymer is accomplished in the stator. The product shown here for illustrative purposes is green, while the two starting components are yellow and blue.




Figure 12. Alternate schemes for detecting cholinesterase activity in the biosensor. This figure shows a variety of possible detection methods, such as qualitative colorimetric changes, chemiluminescent for a dark environment, and additional amplification by coupling the ChE reaction to choline oxidase.




Figure 13. Model of a carbon electrode with immobilized cholinesterase enzyme.




Figure 14. Using high fluoride ion concentrations to reverse the reaction between the OP and ChE. This reaction will permit the determination of the type of OP bound to the badge.




Figure 15 Reactivation of Alkylphosphorylated ChE with Oxime




Figure 16A. Enzyme activity of immobilized FBS-AChE.




Figure 16B. Enzyme activity of immobilized Eq-BChE.





Figure 17. Inhibition of foam-immobilized FBS-AChE by DFP and reactivation by HI-6.



5 Figure 18. Inhibition of foam-immobilized Eq-BChE by DFP and reactivation by TMB4.




Figure 19A




Figure 19B




Figure 20A: The pH profile of soluble and immobilized choline oxidase.




Figure 20B: Substrate concentration dependent curve for soluble and polyurethane coupled choline oxidase.




Figure 21A. Temperature profile of Immobilized and Soluble AChE




Figure 21B. Temperature profile of Immobilized and Soluble BChE




Figure 22




Figure 23: Inhibition of AChE-sensor by the organophosphate MEPQ, which is not reversed by washing in water or buffer.

Figure 24A: protection afforded by sponge with tetraglyme additive.






Figure 24B: protection afforded by sponge with HI-6 additive.



5

Figure 24C: protection afforded by sponge with 2-PAM additive.






Figure 25





Figure 26A: AChE-Sensor Activities after Continuous Incubation at 25°C at Different pHs



5 Figure 26B: BChE-Sensor Activities after Continuous Incubation at 25°C at Different pHs




Figure 26C. AChE-Sensor Activity after Continuous Exposure to Chesapeake Bay
(Brackish) Water at 25°C




Figure 26D: AChE-Sensor Activity after Continuous Exposure to Allegheny River
(Fresh) Water at 25°C




Figure 26E. Sensitivity of M272 ticket to aqueous conditions (Chesapeake Bay brackish water)




Figure 26F. Sensitivity of M272 ticket to aqueous conditions (50 mM phosphate buffer, pH 8.0)




Figure 27A. Dose-dependent inhibition of Immobilized AChE sensor and soluble AChE to the Pesticide Dichlorophos




Figure 27B. Dose-dependent inhibition of Immobilized AChE (sensor) and soluble AChE to the organophosphate soman (GD)